Simplicity
REG. U. S. PAT. OFF.

FRONT MOUNTED CULTIVATOR

INSTRUCTIONS AND PARTS LIST

PACKING LIST

The front mounted cultivator is shipped complete in a carton.

INSTRUCTIONS FOR ASSEMBLING

1. Mount wheels to standards (1) and clamp to push bar (2) as shown.

2. Bolt cultivator shovels to tool holders as illustrated at (3).

3. Attach tool standards to right and left gang tool holders with shank clamps as shown at (4).

4. Clamp right and left gang tool holders to push bar as shown at (5) and (5).

5. Attach cultivator to tractor with Quick Hitch. (See special Quick Hitch instructions in Tractor Manual.)

ADJUSTMENTS

Adjustments for depth are obtained by raising or lowering the tool and wheel standards.

Each shovel can be adjusted individually for pitch.

Loosen nut on bolt (6), adjust, and retighten nut.

LUBRICATION

Grease wheel bearings frequently.



ARTICLE 990022 1156-55

How to Order Repair Parts for Simplicity Garden Tractors and Attachments

The Authorized Simplicity dealer from whom you purchased your tractor and attachments can supply you with any replacement parts you may need. For prompt service, be sure to see your dealer first. He will furnish the correct parts from his stock or order them for you if necessary. However, you may mail-order directly from the factory.

To have your order filled correctly and for prompt service, please furnish the following information:

1. Model, number and year of purchase of tractor or attachment.
2. Part number, description, and quantity of part. (See parts list)

Be sure to include postage with your order. We do not pay transportation charges. Shipping weights are shown. Any excess will be promptly refunded.

We reserve the right to change construction, specifications, prices and terms, without notice and without obligation as to tractors and attachments heretofore shipped.

PRICES SHOWN ARE U.S.A. PRICES. PRICES OUTSIDE OF U.S.A. SUBJECT TO LOCAL IMPORT DUTIES, TAXES, ETC.



Being replaced by 112057 Standard

FRONT MOUNTED CULTIVATOR PARTS LIST

Order by Part Number

Item No.	Part No.	Name of Part	Ship. Wt. Lbs.	Ship. Wt. Oz.	Price Each
1	SSA-54A	Gauge Wheel Spindle 826105-4	6		$ .50
2	SSA-55	Gauge Wheel Washer 826105-5	2		.20
3	SSA-A3	Gauge Wheel Standard 827103	6		.15
4	SSA-A14A	Cultivator Steel w/bolt - 827101-4	8		.60
5	SSA-A18	Tool Standard - 827101-8	2		.70
6	SSA-A23	Shank Clamp - 827102-3	1	8	.45
7	SSA-AX3	Tool Holder Assembly - 827150-3			.50
8	S1B-X1	Hitch Clamp Assembly - 816250-1			1.00
9	103001	Hitch Side Plate -	12		.15
10	S1A-41A	Wing Nut Complete - 816104-1	4		.50

Order by Part Number

Item No.	Part No.	Name of Part	Ship. Wt. Lbs.	Ship. Wt. Oz.	Price Each
11	SSA-AX6 827150-6	Wheel Complete With Juvenile Tire 10 x 1.75 ~~82~~	10		$4.85
12	SSA-CX3 827350-3	Right Hand Tool Frame Ass'bly	7	8	3.30
13	SSA-CX4 827350-2	Left Hand Tool Frame Ass'bly	7	8	3.30
14	SSA-CX5 827350-5	Push Arm Assembly	13		2.00
15	SSA-A240 827124-0	Tire — 10 x 1.75	3		1.46
16	SSA-B28	Wheel Only	6		3.70
17	827202-8	# 1641 Grease Fitting		2	.10
		(Part Not Illustrated)			
	SSA-A27 827102-7	Wheel Bushing		4	.10